

Tischhalterung EASY ARM 1 & 2

- Schalten Sie das Gerät aus und trennen Sie es von der Stromversorgung.
- Öffnen Sie den Deckel und entfernen Sie die Filter.
- Montieren Sie die Rückplatte mit den beiliegenden Schrauben.
- Setzen Sie das Gerät in umgekehrter Reihenfolge wieder zusammen.
- Öffnen Sie die Klemmschraube und schieben Sie die Halterung bis zum Anschlag über die Tischplatte. Ziehen Sie die Klemmschraube fest an.
- Stellen Sie sicher, dass die Tischhalterung fest sitzt.
- Hängen Sie das Gerät mit den Schraubenköpfen in die Tischhalterung ein.

Table Clamp EASY ARM 1 & 2

- Switch off the device and remove the power cable from the power supply.
- Open the cover and remove the filters.
- Mount the backplate of the table clamp as shown and fix them with the enclosed screws.
- Put the device together in reverse order.
- Open the clamp screw, slide the clamp fully over the table plate. Close the clamp screw tightly.
- Make sure that the table clamp is mounted correctly.
- Let the two screws slide into the keyhole openings of the frontplate in order to mount the device.

